



EWMPC/20

Software manual

Diplomatic Oleodinamica Spa

| | |
|---|-----------|
| GENERAL INFO | 3 |
| SYSTEM REQUIREMENTS & SETTINGS:..... | 4 |
| Installation..... | 4 |
| Setting the windows latency timer..... | 5 |
| USER INTERFACE..... | 7 |
| Control bar [1]..... | 7 |
| Tool bar [2]..... | 8 |
| Status bar [3]..... | 8 |
| Right panel functions [4]..... | 9 |
| HOW TO START | 10 |
| Communication settings..... | 10 |
| Link the module..... | 11 |
| SOFTWARE FUNCTIONS | 12 |
| General parameters..... | 12 |
| LG..... | 12 |
| MODE (Input MODE parameter)..... | 12 |
| SENS (sensor monitoring)..... | 12 |
| SIGNAL (type of input)..... | 12 |
| Monitor Tool..... | 13 |
| Process Parameter panel..... | 13 |
| Remote control/Status Info panel..... | 14 |
| Oscilloscope Tool..... | 15 |
| Channel panel..... | 16 |
| Diagram window..... | 17 |
| Terminal Window..... | 18 |
| APPENDIX: MATH and EASY mode | 19 |
| Input signal (AINMODE MATH):..... | 19 |

GENERAL INFO

This is the **software manual of EWMPC/20 software**. It displays information for installation, settings and use of the software EWMPC/20 version 3.6.

For earlier versions please refer to EWMPC/10 software pack.

EWMPC/20 software is a graphical interface for the digital communication and parameterization of EWM digital control cards.

The software is full of advanced diagnostic programs and oscilloscope with measure functions. It allows the parameters to be saved and imported as needed for fast card replacement and to reduce the start-up time of a system.

The software is suitable for:

digital cards EWM series 20 with USB interface port

Should you have any questions concerning just the software, please contact Diplomatic Oleodinamica S.p.A., indicating the software name and version, and a brief description of the system / application.

Other documents to be consulted for complete information are:

Start-up manual of the card

Technical catalogue of the card

Before installation read this file and follow strictly what is indicated.

Diplomatic Oleodinamica disclaims any liability for damage to person or property resulting from noncompliance of rules and instructions here declared, from misuse or incorrect use of this software pack.

Contacts

Diplomatic Oleodinamica S.p.A.

via Mario Re Depaolini 24

I-20015 Parabiago (MI)

ITALY

fax number: +39 0331.895.249

tel. number: +39 0331.895.111

e-mail: support@duplomatic.com

<http://www.duplomatic.com>

SYSTEM REQUIREMENTS & SETTINGS:

The EWMPC/20 program can run on all Windows computers with OS Windows 7 or later versions.

Installation

The installation pack includes both software and driver for the USB communication.

Install the program EWMPC/20 in your Personal Computer:

- Open program folder and select the setup icon to start auto installation
- Follow the guided procedure to complete the installation
- After successful installation of the "program and drivers", an icon will appear on your desktop.




Setting the windows latency timer



To optimize the use of some functions, for example the oscilloscope, the interface latency time should be set to the smallest value possible. Ideally the time should be one millisecond (ms).

The USB interface transmits the data in blocks in the set time interval. If this time interval is larger than the oscilloscope's current sampling time, faultless operation is impossible.

The time is set in the Device manager in the Windows Control Panel.

Caution! Be careful and select the right interface.






USER INTERFACE

At the end of the setup procedure the software can be executed using the proper desktop icon



Launch the program, and the workspace appears.

This is the first screen:



Control bar [1]

- File* : Use this menu to Load or Save offline set of parameters and for usual "File" operations.
- Options*: To change settings
- Help*: Software information and Instruction Manual

Tool bar [2]

Tool bar shows icons grouped for functions:
Communication, Software Functions, File Options and Settings.
Tooltip help the user to identify different actions.

In *Communication* section:



The proper Communication port can be selected



the communication can be established
NOTE: Remember to disconnect the software before switching off a module.



Identification of the model of EWM card and reading of all the parameters

The main panel shows the parameters. There are also other *Functions* implemented on EWMPC that are selectable using the icons in the tool bar:



Parameter list



Monitor (page [13](#))



Oscilloscope (page [15](#))



Terminal (page [18](#))

Status bar [3]

In the status bar useful information can be read:

- Status of the communication
- Settings used for the communication
- Model of card identified

Right panel functions [4]

SAVE: the data are stored in the EEPROM of the module permanently.


DEFAULT: the set in factory is activated again.

LOADBACK: the last stored data are back read.

UPLOAD  and DOWNLOAD  PARAMETERS:

UPLOAD icon will save all parameters (stored into the card) into the PC.


DOWNLOAD icon will send the parameters to the card

ATTENTION: Parameters are not stored into the memory so in case you do not save  the parameters they will be lost when connection is closed.

HOW TO START

Communication settings

Click on "settings" icon 




Select the right port (COM1, COM2, COM3, COM**)

Select TRANSFER MODE

TRANSFER MODE:

Full-Duplex, for EWM cards


Half-Duplex (19200 Baud), for proportional valves

Confirm settings by click on 

Link the module

Press the button CONNECT  to start the communication.

Press Search Module (Identify)  to run the application that will recognize the EWM card linked to the PC.



The screenshot shows the software interface for EWMPC/20 3.5. The main window displays a table of parameters with columns for Command, Parameter, and Help. The 'LG' row is highlighted. To the right of the table is a 'Module Commands' panel with buttons for 'Save', 'Default', and 'LoadBack'. Below that is a 'Parameter Import / Export' panel with buttons for connecting to a module and identifying it. At the bottom, a status bar shows 'port open Port: 3 FDX 57.6 Kbaud EWM-ST-AA -20 -r01'.

| Command | Parameter | Help |
|-----------|-----------|---|
| LG | EN | Deutsch (DE)/English (EN) - Bitte ID Button nach der Aderung dücken |
| MODE | STD | Parameter mode |
| SOLENOIDS | 0 | Connected solenoid count |
| SENS | ON | Malfunction monitor |
| HAND:A | 5000 | Manual speed [0,01%] |
| HAND:B | -5000 | Manual speed [0,01%] |
| INPOS | 200 | In-position-window [um] |
| SYS_RANGE | 50 | Axis working stroke [mm] |
| SIGNAL:X | I4-20 | Type of input |
| N_RANGE:X | 50 | Sensor nominal length [mm] |
| OFFSET:X | 0 | Sensor offset [um] |
| SIGNAL:W | I4-20 | Type of input |
| SIGNAL:V | OFF | Type of input |
| VELO | 10000 | Internal speed limitation [0,01%] |
| ACCEL | 10 | Acceleration [mm/s^2] |
| VMAX | 10 | Maximum speed [mm/s] |
| V0:A | 5 | Loop gain [1/s] |
| V0:B | 5 | Loop gain [1/s] |
| V0:RES | 1 | Loop gain resolution |
| CTRL | SQRT1 | Control characteristic |
| MIN:A | 0 | Deadband compensation [0,01%] |
| MIN:B | 0 | Deadband compensation [0,01%] |
| MAX:A | 10000 | Output scaling [0,01%] |
| MAX:B | 10000 | Output scaling [0,01%] |

After the start screen, the software is ready and you may change the parameters.

(Parameters are related to the type of EWM card that has been connected)

SOFTWARE FUNCTIONS

General parameters

Parameters showed by the EWMPC depend on the card type connected and are described in detail in related start-up manual..

Below you can find the description of general parameters used for all the modules.

LG

This command defines the language of text parameters. Deutsch (DE) / English (GB)

After changing the language setting the ID button in the menu bar must be pressed to see the modification.

MODE (Input MODE parameter)

This command defines the level of setting parameters. STANDARD / EXPERT mode

SENS (sensor monitoring)

| Command | Parameters | Unit | Group |
|-------------|----------------|------|-------|
| SENS x | x= ON OFF AUTO | - | STD |

Activation of the sensor and internal failure monitoring.

ON: All monitoring functions are active. Detected failures can be reset by deactivating the ENABLE input.

OFF: No monitoring function is active.

AUTO: Auto reset mode. All monitoring functions are active. If the failure does not exist anymore, the module automatically resumes to work.

SIGNAL (type of input)

This command can be used to change the type of input signal, voltages (U) or current (I) and to define the polarity of the signal. This command is used to configure the analogue input, if it is available for the module connected.

Also the type of parameters depends on the module connected

| Command | Parameter | Unit | Group |
|---------------|---|------|-------|
| SIGNAL:i x | x= OFF U0-10 U10-0 I4-20 I20-4 | - | EASY |

Monitor Tool

Click  to start MONITOR function.

With the monitor function the individual process data can be observed.

Process Parameter panel

The process parameter panel shows the current process data and where they can be measured.

This panel can be customized from the user, clicking on the *Settings* icon. In the monitor palette, you can set the number of the parameters to be shown.

User can change the number of parameters displayed using Setting windows: user can choose between the standard view (4 parameters), custom (up to 10) and maximum (all parameters).

Then choose the parameter to be monitored in the dropdown list.


Process data are values which are necessary for open or closed loop control.

The most important process data are the demand value (w), the actual value (x) and the output variable (u).

The current process data and where they can be measured in the module, can be seen in the different block diagrams. With "options" the selection can be changed and / or the module set-up can be loaded.

The selection of the process data can be carried out with OPTIONS / SETUP.

The process data are represented continuously.



There will be no indication if process data chosen are not available in the module.

Remote control/Status Info panel

This tool offers other useful additional features that allow easy control during start-up and diagnosis. They are located in the *Remote control/Status Info* panels on the right half of the window. They are:

- Enable/Stop Remote Control checkbox
- Analogue Inputs
- Digital inputs / Outputs
- Status Info

Analogue Inputs

The respective operating components (input fields) are labeled with the appropriate terminal names of the module so the input can be easily identified by looking at the block diagram.

To change a value, double-click with the right mouse button on the field or click in the field and then press the *ENTER* key.

When activated, the box changes color and the text turns red. The slider below becomes active.

Now the changes can be made either by direct numeric input or via the slider.

Caution! Direct numeric input only becomes effective after the *ENTER* key is pressed a second time.

This deactivates the input field again. On the other hand, changes made with the slider take effect immediately.

Input is completed when another input component receives the focus or the *ENTER* key is pressed again in the active input field.

Digital Input and Output

The status of the digital inputs/outputs can be modified only if the remote control function is enabled.

The names of the inputs/outputs are referred to the module's terminals.

Although they are displayed, not all inputs/outputs are actually present on the card: this is necessary for reasons of downward compatibility of the software with other module models.

The specific configuration of the terminals can be inferred from the module's block diagram.

Status Info

Status information are displayed in the lower area of the window, like light-emitting diodes (LEDs).

The LEDs are divided into three different categories.

The green LEDs signal stand-by messages, the yellow ones give status information and the red ones display error messages.


As additional assistance, a small yellow help text label appears when the mouse is moved over an LED or its name.

Oscilloscope Tool

To start the Oscilloscope tool push the Oscilloscope  button.

The setting options  for the oscilloscope are limited to various color settings and line width for the signal curves (channels).


Unlike the color settings, the line width applies to all channels at the same time.



The oscilloscope enables the assessment of the different process variables.

The selection of the process variables is just the same as for the MONITOR tool.

Up to four signals can be displayed simultaneously.



Channel panel

The left panel shows the channels settings:

UPPER LIMIT and LOWER LIMIT

With these two values the vertical scaling of each channel can be set. Obviously, the upper limit must be greater than lower limit.

TIME SCALE

Here the full time period of the indicated curve can be set.

With **START** and **STOP** buttons the data recording can be controlled.

SAVE TO FILE

To log the readings of the channel activated, press "SAVE TO FILE" button and select an existing txt file. When the acquisition is launched through the Start Button, the software saves the reading in the log file selected.

By this way to append more than an acquisition session in the same file is also possible.


Diagram window

The oscilloscope works in the roll / scroll mode so the diagram is always updated at the last seconds. A sampling rate of up to 10ms can be achieved depending from the module model and the baud rate set.

The screen oscilloscope in the EWMPC/20 software has a feature that permits to measure individual signal both horizontally and vertically, using four guides that you can place with drag and drop. The measurement info are displayed in the status bar.

To activate the guides, right-click on the grid area and select *Scope cursor setting* from the context menu that will appear.

A pop-up dialog box permits to choose the channel and the type of measurement (time, amplitude or both).



It's possible to capture the oscilloscope screen to the clipboard for further editing.


To capture the grid area, right-click on the grid area and select *Copy Scope Display* from the context menu that will appear.

It's also possible to print the oscilloscope view for documentation purposes.

The cursor coordinates, a key to the channels and the scale values are also printed together with the chart. Click on the print button in the main bar to start printing.

Terminal Window

Use terminal window to display or modify parameters using command lines.



Type the name of the parameter and press enter to display the value of the parameter.

Type the name of the parameter followed by the value to assign to modify the current setting.

APPENDIX: MATH and EASY mode

With the advent of series 20 a new management of analogue signal settings is introduced. The previous scaling method is still available by changing the proper parameter through the Terminal window.

Using the following two lines of code the software will switch between 'Easy' mode and 'Math' mode, respectively:

```
AINMODE EASY
```

```
AINMODE MATH
```

In MATH mode the analogue signal parameters will be displayed in a different way:

| Command | Parameter | Help |
|-----------|----------------|---|
| LG | EN | Deutsch (DE)/English (EN) - Bitte ID Button nach der Änderung drücken |
| MODE | EXP | Parameter mode |
| SOLENOIDS | 0 | Connected solenoid count |
| SENS | ON | Malfunction monitor |
| EOUT | 0 | Output signal if not ready [0,01%] |
| HAND:A | 2500 | Manual speed [0,01%] |
| HAND:B | -2500 | Manual speed [0,01%] |
| INPOS | 50 | In-position-window [µm] |
| SYS_RANGE | 500 | Axis working stroke [0,1 mm] |
| AIN:X | 666 533 2000 C | Mathematical scaling of the input |
| AIN:W | 666 533 2000 C | Mathematical scaling of the input |
| SIGNAL:V | OFF | Type of input |
| VELO | 5000 | Internal speed limitation [0,01%] |
| VMODE | NC | Method of positioning |
| ACCEL | 250 | Acceleration [mm/s^2] |
| VMAX | 50 | Maximum speed [mm/s] |
| V0:A | 500 | Loop gain [1/s] |
| V0:B | 2500 | Loop gain [1/s] |
| V0:RES | 100 | Loop gain resolution |
| PT1 | 1 | PT1-filter time constant [ms] |
| CTRL | SQRT1 | Control characteristic |
| MIN:A | 0 | Deadband compensation [0,01%] |
| MIN:B | 0 | Deadband compensation [0,01%] |
| MAX:A | 10000 | Output scaling [0,01%] |

Input signal (AINMODE MATH):

Input AIN:W Parameter

Parameter

A: 1250 A / B

B: 1000 A / B

C: 2000 0,01%

X: c

Unit: V (Voltage) or C (Current)

Presetting: user defined, 0 - 10V, 4 - 20mA

$Y = A / B * (X - C)$

Comment: Mathematical scaling of the input

OK Cancel

USER DEFINED:

| Command | Parameters | Unit | Group |
|--------------|---------------------------|--------|-------------|
| AIN:i | | | MATH |
| A | a= -10000... 10000 | - | |
| B | b= -10000... 10000 | - | |
| C | c= -10000... 10000 | 0,01 % | |
| X | x= V C | - | |

With this command each input can be scaled individually. For the scaling function the following linear equation is taken.

$$y = \frac{a}{b} \cdot (x - c)$$

x is the input signal and **y** is the output signal.

At first, the offset (*c*) will be subtracted (in 0,01% units) from the input signal, then the signal will be multiplied with factor *a* / *b*. With these both factors every floating-point value can be simulated (for example: 1.345 = 1345 / 1000).

With the *x* parameter value the internal measuring resistance for the current measuring (4... 20 mA) will be activated (*V* for voltages input and *C* for current input).

| | AIN:xx | a | b | c | x |
|---------------------|---------------|----------|----------|----------|----------|
| i with voltage (V): | AIN:i | 1000 | 1000 | 0 | V |
| i with current (C): | AIN:i | 1250 | 1000 | 2000 | C |

Reverse acting sensor works from 10 V to 0 V.

| | AIN:xx | a | b | c | x |
|---------------------|---------------|----------|----------|----------|----------|
| i with voltage (V): | AIN:I | -1000 | 1000 | 10000 | V |

0...10V

To set this input select from right selection menu "presetting" 0...10V then click 

4...20mA

To set this input select from right selection menu "presetting" 4...20mA then click 